

OSC addresses and values for iControl OSC & NDI app

Parameter	OSC Address	Value type	Value range	Behaviour
Touch pad X axis	/touchX	Float	[-0.5, 0.5] Or [-1, 1]	Sending the value only when the finger touches the pad - The [-0.5, 0.5] range is used for the combo touch pad + sliders/ buttons - The [-1, 1] range is used for the touch-pad-only mode
Touch pad Y axis	/touchY			
Slider 1	/slider1	Float	[0, 1]	Continuously sending the value
...	...			
Slider 10	/slider10			
Button 1	/toggle1	Integer	{0; 1}	Continuously sending the value
...	...			
Button 10	/toggle10			